




BlackBerry 8820 LCD Screen Replacement

Step by step guide to replace the screen.

Written By: ryan



INTRODUCTION

Replace your cracked LCD screen with a new one.



TOOLS:

- [iFixit Opening Tools](#) (1)
 - [64 Bit Driver Kit](#) (1)
-

Step 1 — Disassembling BlackBerry 8820 Outer Casing



- Remove the battery cover, by applying pressure and sliding down to the silver square on the back of the phone.

Step 2



- Remove the battery by prying under it with your finger or the plastic opening tool.
- Remove the four small 3/8" long screws using a 1/16" diameter torx screwdriver.

Step 3



- Use a plastic opening tool (similar to the one shown) to carefully remove the two side bars of plastic.

Step 4



- Use the plastic opening tool to carefully pry the back casing off.
- ⓘ There are two small clamps on each edge that need to be unhooked before the casing will come off.

Step 5



- Pry off the front casing
- ⚠ ***Be aware of sensors and other sensitive areas of the newly exposed electronics***

Step 6 — LCD Screen



- After disassembling the outer casing, the phone should be stripped as shown.

Step 7



- At the top of the phone, locate the gloss SATA cable strap connecting the LCD screen to the phone.
- Using the prying tool, unattach this cable by levering under the connector.

Step 8




- Using the prying tool, lever up the old screen as shown.



WARNING: Be sure to have disconnected the SATA cable strap prior to attempting this.

Step 9



- Insert new LCD screen.
- Attach cable to the connector located at the top of the phone.
- Phone should look as it was prior to screen removal.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-20 01:57:00 AM.